

Quick Start Setup Guide

C31 Drone Quick Start Guide

- **Unboxing inspection**
 - Check that all items match the shipping list.
 - **Register a pilot account**
 - Please register and log in at:
<https://drone.ceresair.com/auth/login?redirect=/plot-management#/login?redirect=/myDrone>
 - **Power on and pairing**
 - After assembling the drone, power it on and pair the remote controller with the aircraft.
Please note: logging in and firmware upgrades require the remote controller to be connected to the internet.
Pairing procedure in the App

Go to **Start** → **Settings (top right corner)** → **Remote Control** → “**The remote controller and the aircraft are linked together**” → **Click “Start Pairing”**
Power on the drone and press and hold any battery power button until the indicator light starts flashing (pairing mode).
The drone will automatically pair with the remote controller.

Activate the drone

 - Log in to the App and activate the drone.
Activation code: **UC5A0FE7**
(The activation page will pop up automatically.)
 - **Upgrade App and firmware**
 - In the App, go to **Device Management** and upgrade both the App and drone firmware to the latest version.
- Tank and flow meter calibration**
- Go to **Start** → **Settings** → **Spray** and follow the instructions to perform:

Empty tank calibration
Full tank calibration
Flow meter calibration
 - Make sure the **Flow Coefficient** value is around **100** (acceptable range: **90–110**).
- **Ready for operation**
 - After calibration, the drone is ready for automatic flight.
For detailed App functions, please refer to the manufacturer’s knowledge base.

Important Notes

A stable and reliable internet or cell network connection is required when updating the App or drone firmware. Poor network connectivity may cause updating failures or firmware issues.